

- ① Pneumatic height (cylinder)
- ② Tension adjustment
- ③ Vertical seat tilt lock

AVAILABLE ON:

- |                |          |
|----------------|----------|
| • Lead         | • Mia    |
| • FX           | • Ply    |
| • X2           | • Zoa    |
| • Rivo         | • Lead V |
| • Spyder SM ST | • Shift  |
| • Dextra       | • Ely    |
| • Urbex        | • Tara   |
| • Link         | • Ema    |



To adjust the chair properly, follow these steps:

**Seat high adjustment** - Adjust the chair height by lifting handle #1. Choose a height that will allow your feet to lean on the floor and your knees to clear the seat to avoid constant pressure on your knees.

**Mechanism tension** - Turn the roulette #2 to adjust the mechanism tension of the chair.

**Lock-in vertical position** - Push the handle inward to lock-in the vertical position. Pull to unlock-it.