

- ① Seat slider
- ② Tension adjustment
- ③ Pneumatic height (cylinder)
- ④ Infinite backrest and seat tilt-lock in 3 positions



AVAILABLE ON:

- Lead

To adjust the chair properly, follow these steps:

**Backrest high adjustment** - Adjust the backrest height by lifting it. Each «click» is a predefined position. To lower the backrest, lift it at the highest and let it drop. This allows you to position the lumbar support at the right position.

**Backrest and seat angle adjustment** - Pull handle #4 outward to unlock the chair and adjust it to the desired angle within one of the three preset positions by rocking back in the chair. If the movement is too difficult or too easy, turn the handle #2 in the appropriate direction to adjust the tension. To lock the chair in place, push handle #4 back in.

**Seat high adjustment** - Adjust the chair height by lifting handle #3. Choose a height that will allow your feet to lean on the floor and your knees to clear the seat to avoid constant pressure on your knees.

**Seat depth adjustment** - Keep the handle #1 lifted up and slide the seat to adjust the depth.